90cm 5 zone induction cooktop with FlexiBridge, Chef Mode, MaxiZone, 14 stage slide controls and Hob2Hood capability.

RRP AUS $2,939.00

Product Details

FEATURES

Flexibility to cook with FlexiBridge	Chef Mode	MaxiZone	Hob2Hood technology
Touch and slide controls Touch the control bar at the necessary heat setting	STOP & GO function	Timer and minute minder	Auto warm-up function
Auto pot detection			

BENEFITS

Your kitchen, your way
Enjoy a kitchen appliance thats versatile enough to handle your most complex dishes. Thanks to FlexiBridge, you can combine your induction segments in a range of ways or use them all at once for the largest single cooking area available. Perfect heat distribution ensures even cooking all the way through.

Cook like a chef
Chef Mode enables you to choose between different preset heated zones by simply sliding your pan across the hob. Go from boiling to simmering to keeping the pot warm by placing it on the different heat zones allowing you full control in the kitchen.

Enjoy the space and freedom to cook what you want
Use large pots and pans like a professional chef. The extra large MaxiZone on this hob gives you the freedom to effortlessly prepare all kinds of dishes that need a large pan with consistent heat, like that delicious paella youve been wanting to cook.

The hands free hood
While you concentrate on the flavours, the innovative Hob2Hood feature will take care of keeping your kitchen fresh. The rangehood automatically turns on as soon as you start cooking, and intuitively adjusts the fan speed with your cooking.

Control at your fingertips
The touch controls on this hob lets you heat up, down or switch off immediately. Just gently slide your finger across the control to the temperature you need and you can be confident it will respond right away, so you can create delicious meals effortlessly. The Stop & Go feature offers a useful keep warm setting if youre unexpectedly interrupted.

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Cooktop type	Induction
Materials/Colour	black ceramic glass

DIMENSIONS

Total product height (mm)	55
Total product width (mm)	910
Total product depth (mm)	520
Cut out width (mm)	880
Cut out depth (mm)	490

CONTROLS

Controls of Cooktops	Touch and Slide controls
Position of controls	front
Functions of Cooktops	stop and go,automatic warm up,timer,Keep warm function,cooking timer with acoustic signal,automatic switch off,power booster,Hob2Hood,FlexiBridge,Chef Mode
Indicators/display	fault indicator,3 level residual heat indicator

ELEMENTS/BURNERS

LEFT FRONT ZONE

Left front zone	induction extended
Left front Watts	2300
Left front boost watts	3400
Left front diameter	210

CONTROLS

Features of Cooktop	safety cut off,overheating protection,electronic timer,minute minder,hot surface indicator,FlexiBridge zone,Chef Mode,function lock,auto pot sensors,child safety device lock,Hob2Hood Connectivity
Timer of Cooktop	programmable 99min,auto off,countdown

LEFT REAR ZONE

Left rear zone	induction extended
Left rear watts	2300
Left rear diameter	210

CENTRE FRONT ZONE

Centre front zone	induction maxi
Centre front Watts	3500
Centre front diameter	280

RIGHT FRONT ZONE

Right front zone	induction
Right front Watts	1400
Right front diameter	145

RIGHT REAR ZONE

Right rear zone	induction
Right rear watts	1800
Right rear diameter	180

ELECTRICAL SPECIFICATIONS

SHIPPING

ELECTRICAL SPECIFICATIONS

Connected load KW	11
Maximum current rating (amps)	45
Type of connection	hardwired

SHIPPING

Shipping Volume (m3)	0.93
Shipping Weight (Kg)	20.0
Pack Dimensions Height (mm)	125
Pack Dimension Width (mm)	635
Pack Dimension Depth (mm)	1170
Total shelf area (m^2)	74.30

STUFFING QUANTITIES

20ft	128
40ft	288
40ft HC	342

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes theproducts that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours ofproducts illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640
fax: 1800 350 067
email: customercare@electrolux.com.au
web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230
fax: 09 573 2221
email: customercare@electrolux.co.nz
web: www.electrolux.co.nz